



【Break Time】

Ceiling, LEDs

【Break Time, Eating Together】

Teapot, Spice Jars



In this issue

The parts in this issue are the Ceiling and LEDs for the 【Break Time】 scene. Also included are the Teapot and Spice Jars to be displayed on the Table in the 【Eating Together】 scene.



CEILING, LEDs

We will assemble the Ceiling for the 【Break Time】 scene by fitting the LEDs into the Ceiling Top Panel on the side of the 【Eating Together】 scene and assembling it with the Inner Panel.



TEAPOT, SPICE JARS

Also display the Teapot and Spice Jars included in this issue, and the small items prepared in previous issues on the Table in the 【Eating Together】 scene in a well-balanced manner.



ASSEMBLY INSTRUCTIONS

【Break Time】


Assembling the Ceiling and LEDs

【Break Time, Eating Together】

Making the Teapot and Spice Jars


In this issue, we will fit the LEDs and Circuit Board to the Ceiling Top Panel of the 【Break Time】 scene and assemble it with the Inner Panel, and display the Teapot, Spice Jars, etc. on the Table in the 【Eating Together】 scene in a well-balanced manner.

Parts of issue 38




- ① Ceiling Top Panel ② Inner Panel ③ Short Cable with LEDs ④ Long Cable with LEDs ⑤ Cable with LEDs for Kitchen Cabinets
⑥ Circuit Board ⑦ Screw (PM2×4mm)×3 (1 for spare) ⑧ Spice Jar×2 ⑨ Lid ⑩ Teapot



ASSEMBLING THE CEILING AND LEDS




Check the orientation of the ① Ceiling Top Panel—refer to the holes shown above to make sure it is facing the correct direction.



Assemble the ⑥ Circuit Board to the ① Ceiling Top Panel by fitting its terminal part into the hole in the ceiling and inserting the ceiling's protrusions into its holes on the left and right.




Tighten the ④ Screws (PM2×4mm) one by one into the two holes in the Circuit Board.




Identify the protrusions (six in total) circled in blue on the ① Ceiling Top Panel. Align the LEDs with these protrusions and affix the Cables with LEDs.


Assembling the Ceiling and LEDs




There are LEDs in two places on the ③ Short Cable with LEDs and in four places on the ④ Long Cable with LEDs.





Affix the ③ Short Cable with LEDs and ④ Long Cable with LEDs in line with the indentations in the Ceiling Top Panel by aligning the LEDs with the protrusions identified in step 4.




Now carefully bend the base of the LED at the end of the ⑤ Cable with LEDs for Kitchen Cabinets at about 90°. Do not bend it back once bent, or the internal wires may break.



Take out the Kitchen Cabinets from the 【Eating Together】 scene and check how the ⑤ Cable with LEDs for Kitchen Cabinets should be fitted—the LED should be inserted into the hole through the opening at the back of the Kitchen Cabinets.



Plug the connectors of the two Cables with LEDs fitted in the Ceiling Top Panel and the connector of the ⑤ Cable with LEDs for Kitchen Cabinets into the sockets on the Circuit Board.



Plug the connector of the Connection Cable into the socket on the other side of the Ceiling Top Panel, then connect it to the Battery Box and check if every LED lights up properly.



【Break Time, Eating Together】




ASSEMBLY INSTRUCTIONS


【Break Time, Eating Together】




Assembling the Ceiling and LEDs




Disconnect the Battery Box and tidy up the three cables as shown.



Assemble the ② Inner Panel to the Ceiling Top Panel.




Insert the protrusions of the Ceiling Top Panel into the holes of the Inner Panel to fit them together. The ⑤ Cable with LEDs for Kitchen Cabinets should be pulled out of the hole as shown in the round photo.



MAKING THE TEAPOT AND SPICE JARS




Place the furniture assembled so far in the 【Eating Together】 scene and display the figurines. If the furniture items (except the Kitchen Cabinets) tend to come off, secure them in place with quick-drying glue.



Fit the ⑨ Lid to the ⑩ Teapot by inserting its protrusion into the hole.



Making the Teapot and Spice Jars




Display the Salad Bowls and Spoons from issue 33, the Cereal Bowls from issue 34, the Bowl from issue 35, and the Teapot and ⑧ Spice Jars from this issue on the Table in a well-balanced manner. You may choose to apply small pieces of double-sided tape to their bottoms.



For those who wish to add extra details to the Cereals

Modellers who wish to can apply a little acrylic paint to add depth to the Cereals made in issue 34. For Snoopy's Cereal, slightly change the colour to add some variety.




Squeeze out the yellow ochre and white paints in a 1:1 ratio and mix with five parts water and a few drops of neutral detergent.



Now apply the paint to the Cereal with a liner paintbrush. The trick is to paint in dots with the brush tip. Let's colour both bowls of Cereal.



For Snoopy's Cereal, add twice as much white to two equal amounts of brown (grayish brown and burnt sienna), and mix with water and neutral detergent as in step 1.



Dip the liner paintbrush in the paint and apply it as in step 2.