



【Fan Favorites, Security Blanket/Snoopy's First Appearance】

Ceiling Top Panel, LEDs, etc.

【Fan Favorites, Security Blanket】

Hanging Cabinet, Cups, etc.

【Figurine】

Lucy 【Security Blanket】

The parts in this issue are the Ceiling Top Panel, LEDs, etc. for the 【Security Blanket/Snoopy's First Appearance】 scene box. Also included are the parts of the Hanging Cabinet, Cups, etc. for the 【Security Blanket】 scene, and the figurine is Lucy for the same scene.

In this issue



HANGING CABINET, CUPS, ETC.

We will decorate the 【Security Blanket】 scene with Cups and other small items, and assemble the Hanging Cabinet near the Ceiling to complete the scene.



Figurine



Lucy

Figurine for the
【Security Blanket】 scene

CEILING TOP PANEL, LEDS, ETC.

We will also assemble the Ceiling of the 【Security Blanket/Snoopy's First Appearance】 scene box by fitting LEDs on both sides of the Ceiling Top Panel and assembling the Inner Panels.

When his grandma removes his security blanket in an attempt to end his dependence on it, Linus clings to a dish towel instead. The downside is that it still has to fulfil its original purpose, as Lucy is quick to demonstrate.





ASSEMBLY INSTRUCTIONS

【Fan Favorites, Security Blanket/Snoopy's First Appearance】


Assembling the Ceiling Top Panel and LEDs

【Fan Favorites, Security Blanket】

Making the Hanging Cabinet, Cups, etc.


We will assemble the Ceiling of the 【Security Blanket/Snoopy's First Appearance】 scene box by fitting LEDs on both sides of the Ceiling Top Panel and assembling the Inner Panels. We will also decorate the 【Security Blanket】 scene with Cups and other small items to complete the scene.

Parts of issue 83




- ① Ceiling Top Panel ② Inner Panel A ③ Inner Panel B ④ Hanging Cabinet Top ⑤ Hanging Cabinet ⑥ Straw×2 ⑦ Cup A ⑧ Cup B ⑨ Long Cable with LEDs ⑩ Short Cable with LEDs ⑪ Hanging Cabinet Cable with LED ⑫ Circuit Board ⑬ Screw (PM2×6mm)×3 (1 for spare) ⑭ Screw (PM2×4mm)×3 (1 for spare) ⑮ Dish Towel 【Figurine】 ⑯ Lucy

ASSEMBLING THE CEILING TOP PANEL AND LEDs



Fit the ⑫ Circuit Board to the ① Ceiling Top Panel as shown.




Tighten the ⑭ Screws (PM2×4mm) into the Circuit Board in the two positions shown.



Affix the ⑨ Long Cable with LEDs and ⑩ Short Cable with LEDs to the Ceiling Top Panel, and plug their connectors into the sockets on the circuit board as we did before.




Assembling the Ceiling Top Panel and LEDs





Get ready the Cable with LEDs from issue 82, affix it to the other side of the Ceiling Top Panel and plug its connector into the socket on the Circuit Board.




Plug the connector of the ⑪ Hanging Cabinet Cable with LED into the remaining socket on the Circuit Board.



Plug the connector of the Connection Cable into the socket on the other side of the Ceiling Top Panel, and connect it to the Battery Box and other parts. Then flip the switch on the Circuit Board for the Battery Box to check that the LEDs light up properly.



② Inner Panel A and ③ Inner Panel B have different numbers of LED holes. Be careful not to mix them up.




Assemble ② Inner Panel A and ③ Inner Panel B to the Ceiling Top Panel as we did before.

Issue 83 Completed




That finishes the Ceiling of the 【Security Blanket/Snoopy's First Appearance】 scene box. Let's go on to complete the 【Security Blanket】 scene.






MAKING THE HANGING CABINET, CUPS, ETC.



Get ready the【Security Blanket】scene assembled in issue 82, and fit ⑦ Cup A to the Sink in the position shown.




Fit ⑧ Cup B next to it in the same manner.



Use a cutter to remove the ⑥ Straws along the seams.




Place one ⑥ Straw in each of the two Cups. You may apply a little quick-drying glue to secure them in place.



Carefully bend the LED base by about 90° at the end of the ⑪ Hanging Cabinet Cable with LED. Never bend it back once bent, or the internal wires may break.



Insert the LED at the end of the ⑪ Hanging Cabinet Cable with LED into the hole in the ⑤ Hanging Cabinet.




Fit the ④ Hanging Cabinet Top onto the ⑤ Hanging Cabinet as shown.

Making the Hanging Cabinet, Cups, etc.



Now fit the assembled Hanging Cabinet from step 15 to the Back Wall. Pull the cable with LED out from the Hanging Cabinet and pass its connector through the rectangular hole in the Back Wall, then insert the cabinet protrusions into the holes in the wall.



If the Hanging Cabinet protrusions are too large to insert into the holes, you can file or trim them carefully with a cutter to adjust them.




Now fit the ⑮ Dish Towel to the dish the ⑯ Lucy figurine is holding. Match the shapes of the dish protrusion with the hole and insert it.



Fit the Lucy figurine to the Floor by inserting the protrusions under her shoes into the holes in the Floor, then place the other end of the Dish Towel between Linus' face and hand.



Tighten the ⑬ Screws (PM2×6mm) into the holes in the long tabs of the Exterior Walls to secure them in place.



Then assemble the Ceiling onto the scene box. Plug the connector of the cable coming up from the 【Security Blanket】scene into the socket on the Circuit Board as you assemble it.

Issue 83 Completed

The 【Security Blanket/Snoopy's First Appearance】 scene box is now complete.

