



【Winter, Christmas Tree】

Christmas Tree, Gift Boxes

【Summer/Winter, Summer Camp/Christmas Tree】

Circuit Board

【Figurine】

Sally 【Christmas Tree】

The parts in this issue are the Christmas Tree and Gift Boxes for the 【Christmas Tree】 scene. Also included is the Circuit Board for the Ceiling of the 【Summer Camp/Christmas Tree】 scene box. And the figurine is Sally for the 【Christmas Tree】 scene.

In this issue



CHRISTMAS TREE, GIFT BOXES

We will complete the 【Christmas Tree】 scene by fitting the figurines, assembling the Christmas Tree, and displaying the Gift Boxes on the Floor.





Figurine



Sally

Figurine for the
【Christmas Tree】 scene



CIRCUIT BOARD

We will also assemble the Circuit Board to the Ceiling of the 【Summer Camp/Christmas Tree】 scene box, and plug in the connectors of the Cables with LEDs.



ASSEMBLY INSTRUCTIONS

【Winter, Christmas Tree】

Assembling the Christmas Tree Making the Gift Boxes

【Summer/Winter, Summer Camp/Christmas Tree】

Assembling the Circuit Board

We will fit the figurines, assemble the Christmas Tree and display the Gift Boxes on the Floor to complete the 【Christmas Tree】 scene. We will also assemble the Circuit Board to the Ceiling and plug in the connectors of the Cables with LEDs.

Parts of issue 92



- ① Tree A ② Tree B ③ Tree C ④ Tree D ⑤ Footstool ⑥ Decoration ⑦ Circuit Board
⑧ Screw (PM2×4mm)×3 (1 for spare) ⑨ Screw (PM2×6mm)×3 (1 for spare) ⑩ Gift Box Sheet 1
⑪ Gift Box Sheet 2 ⑫ Gift Box Sheet 3 【Figurine】 ⑬ Sally

【Winter, Christmas Tree】




Assembling the Christmas Tree

5



Then fit the Snoopy figurine from issue 91 as shown.


6



Taking care not to dislodge the figurines, assemble ① Tree A onto the Floor by inserting its four bottom protrusions into the holes circled in red above.


ASSEMBLING THE CHRISTMAS TREE

1



Refer to the bottom protrusions to determine the correct orientation of the ⑤ Footstool.


2



Get ready the 【Christmas Tree】 scene assembled in issue 91, and assemble the ⑤ Footstool onto the Floor by inserting its bottom protrusions into the holes in the Floor.




7




As in step 4, fit one of the Woodstock and Friends figurines from issue 91 to the inner side of ② Tree B as shown.

8




Assemble ② Tree B on top of Tree A as shown by inserting its five protrusions into the holes in the tree below.

3




Fit the ⑥ Decoration into ① Tree A in the position shown. Match the shape of its protrusion with that of the hole and insert it.

4




Get ready the Woodstock and 3 Friends figurines from issue 91 and fit one to the inner side of ① Tree A as shown.

9



Fit the ⑬ Sally figurine to the tree and place her feet on the Footstool assembled in step 2.




Fit the remaining two Woodstock and Friends figurines from issue 91 to the inner side of ③ Tree C.







Assembling the Christmas Tree



Assemble ③ Tree C as in step 8, then assemble ④ Tree D.




MAKING THE GIFT BOXES




Cut to remove Box A along the seams of ⑫ Gift Box Sheet 3.



Lay Box A in the orientation shown and fold over the top right side.



Next, fold over the bottom right side and insert its tab into the pocket-shaped part. Also fold up the top left side in the same manner.



Now fold the opposite side as in steps 13~14. After that, apply a little glue to the four inner corners to secure them.



Then fold over the top side in the same manner to make it box-like with a closed lid.




Make the Gift Boxes using Boxes B~H as in steps 12~16.

Making the Gift Boxes




Fold Box I as shown and glue it into a rectangular tube.




Then fold up the tabs on the left and right sides and insert them into the inner sides of the tube.



ASSEMBLING THE CIRCUIT BOARD



Get ready the Ceiling of the 【Summer Camp/Christmas Tree】 scene box assembled in issue 91, and assemble the ⑦ Circuit Board in the orientation shown.



Tighten the ⑧ Screws (PM2×4mm) into the two positions shown to fasten the Circuit Board, and plug the connectors of the three Cables with LEDs into the sockets on the Circuit Board.



Get ready the 【Summer Camp/Christmas Tree】 scene box, and tighten the ⑨ Screws (PM2×6mm) into the holes in the long tabs of the Exterior Walls to fasten the walls.

